

# Sysex Midi Remote Page For User Control Medium

## C-Console:

- 1- Go to **Setup/ Midi Remote** – Check your connection and go **Online**
- 2- Go to **Inpatchmap**
- 3- **Add Controller**
- 4- Right-click on **Controller** and choose **Learn**
- 5- Quickly move a controller on your external device
- 6- Right-click on **Controller** and choose **System Exclusive...**
- 7- **String looks something like this:**  
F0,43,10,3E,04,30,00,0C,34,F7
- 8- Now exchange the value before the last one to VALUE  
**(Now)**  
F0,43,10,3E,04,30,00,0C,VALUE,F7
- 9- Select **OK** and Exit the Sysex view
- 10- Select **Linear**
- 11- Right-click on **Channel** and choose **Midi Remote/ RemCh1 0**
- 12- Right-click **Parameter-** Select **User Variable 3** (Fader 1 of Medium User Control)  
**\*\*\*\*Remember\*\*\*\***  
*Move a parameter in your User Medium Control and check your DATA window to see what parameter you are assigning!*
- 13- Now move external controller and see if the Fader moves...if not, **repeat steps 4-10** till success
- 14- Now **Make Outmap**

***Voila***

**Midi Remote Fader Ch.1 of Medium User Control** is now connected to your Remote Controller with Two-way communication capabilities!

**Repeat process until you have created a full control panel!**